SERVICE MANUAL

MODEL 1084P MONITOR includes 1084P-S SCHEMATIC

JULY, 1988

PN-314890-01



SERVICE MANUAL

MODEL 1084P MONITOR

includes 1084P-S SCHEMATIC

JULY, 1988

PN-314890-01

Commodore Business Machines, Inc.

1200 Wilson Drive, West Chester, Pennsylvania 19380 U.S.A.

Commodore makes no express or implied warranties with regard to the information contained herein. The information is made available solely on an as is basis, and the entire risk as to completeness, reliability, and accuracy is with the user. Commodore shall not be liable for any damages in connection with the use of the information contained herein. The listing of any available replacement part herein does not constitute in any case a recommendation, warranty or guaranty as to quality or suitability of such replacement part. Reproduction or use without express permission, of editorial or pictorial content, in any matter is prohibited.

This manual contains copyrighted and proprietary information. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Commodore Electronics Limited.

Copyright © 1988 by Commodore Electronics Limited. All rights reserved.

IMPORTANT SAFETY NOTICE

Proper service and repair is important to the safe, reliable operation of all NAPCEC Equipment. The service procedures recommended by NAPCEC and described in this service manual are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment. It also is important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. NAPCEC could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, NAPCEC has not undertaken any such broad evaluation. Accordingly, a servicer who uses a service procedure or tool which is not recommended by NAPCEC must first satisfy himself thoroughly that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

WARNING

Critical components having special safety characteristics are identified with an S by the Ref. No. in the parts list and enclosed within a broken line* along with the safety symbol on the schematics or exploded views.

Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from the N.A.P. Consumer Electronics Corp. NAPCEC assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.

^{*} Broken line: ____ . ___ . ___ .

INDEX

INDEX	
Description	Page
Adjustment Procedures	4-7
CRT P.C. Board (component side view)	
Interconnect Diagram	
Interface P.C. Board (component side view)	14, 22
Main P.C. Board (component side view)	9, 17
Power Supply P.C. Board (component side view)	15, 16
Replacement Parts List	
Safety Notes	
Schematic Diagram	
Schematic Notes	10, 18
Specifications	
Waveforms	8
SPECIFICATION	
CRT size	13 inch diagonal
CRT Deflection Angle	90 degrees

SPECIFIC CRT size CRT Deflection Angle CRT Mask Pitch:	ATIONS 13 inch diagonal 90 degrees
-8CM505/CM8505/CM870 -8CM515/8CM542/CM856 -8CM643 CRT Light Transmission:	05 0.65mm 62/CM8762 0.42mm 0.39mm
-CM8505/CM8705 -8CM505/8CM515/8CM64 -8CM542/CM8562/CM876 Power Requirements	
Power Consumption Degaussing	75W max. Automatic (when switching on set)
Video Input Signals: CM8505/CM8705/8CM50 RGR a	
Composite video	6 pin connector 1Vp-p,
	gative sync, RCA connector RGB-1 TTL, separate horiz. and vert. sync,
Horizontal Scanning Freque Horizontal Frequency Drift	8 pin connector ncy 15734Hz 1 % max.
Horizontal Flyback Time Horizontal Blanking Time	12uS max. 12uS max.
Vertical Scanning Frequenc Vertical Frequency Drift Vertical Flyback Time	y 47-62.5Hz 1% max. 0.95mS max.
Vertical Blanking Time RGB Amp Bandwidth	(21H) 1.33mS 8MHz min.
RGB Amp Bandwidth (8CM) Resolution: -Vertical	543) 15MHz min. 240 lines
-CM8505/CM8705 Horizon -8CM505 Horizontal	390 dots
-8CM515/CM8562 Horizon -8CM542/8CM643 Character Display:	640 dots 690 dots
-CM8505/CM8705 -8CM505 -8CM515/8CM542/CM856	1000 characters (40 x 25) 1600 characters (64 x 25) 52/CM8762/8CM643 2000 characters (80 x 25)
Overshoot/Undershoot Black Level Shift Audio Input Signal Audio Input Impedance	5% max. 3% max. 150mV eff. 10k
Audio Output Power Audio Frequency Range Audio S/N Ratio	1W a 5% distortion 300Hz - 7kHz 40dB min.
Operating Humidity Range Dimensions (HxWxD)	less than 80% 320x350x387mm

^{*} Specifications subject to change without notice.

ADJUSTMENT PROCEDURES

Adjustment Notes:

unless otherwise specified:

- An isolation transformer must be used when servicing this unit.
- 2. Line voltage maintained at 120Vac, 60Hz.
- 3. The unit should be allowed to warm up for at least 30 minutes prior to making any adjustments.
- 4. Voltages measured with repect to ground.
- Signal injection point is the Video In Jack.

R496 Pincushion Adjustment (8CM643 only)

- Inject a cross-hatch pattern and set Brightness Control (R598) and Contract Control (R585) to their mechanical centers.
- Adjust R496 so that 14 blocks correspond to a width of 26cm.
- 3. Horizontal Amplitude and Centering Adjustment
- 4. Vertical Amplitude and Centering Adjustment

R598 Sub-Brightness Control Adjustment (8CM643 only)

(Dual Trace Oscilloscope required)

- 1. Inject a signal with a white raster to input connector.
- Adjust G2 (R727) and Contrast Control to minimum. Adjust Brightness Control to mechanical center.
- 3. Connect a DC coupled probe from Channel A of the oscilloscope to pin 1 of IC502.
- Connect a DC coupled probe from Channel B of the oscilloscope to the emitter of TS641.
- 5. Adjust the Sub-Brightness (R598) to place the top of the video Signal (Channel A) at the same voltage level as the emitter of TS641 (Channel B).
- Adjust Red (R705), Green (R705) and Blue (R706) cut off controls to set pins 6, 8, and 11 of Picture Tube at 100 volts each.
- 7. Advance G2 control (R727) until screen just begins to illuminate.
- If the electron guns of the CRT are balanced, you should get a dull gray raster. However, if one color is more predominant than the others, adjust the cutoff controls of other 2 corresponding guns as required to obtain a gray raster.

Power Supply Adjustment

- With the unit off, set the Volume Control (R316), Contrast Control (R585), and Brightness Control (R589) to minimum.
- 2. Preset R114 to mechanical center.
- 3. Connect a voltmeter across C494 and turn on the
- 4. Adjust R114 for a reading of 125V on the meter.

Horizontal Synchronization Adjustment

- Inject a cross-hatch pattern signal and short C434.
- Adjust the horizontal sync with R437.
- 3. Remove the short from C434.

Vertical Synchronization Adjustment

- 1. Inject a cross-hatch pattern signal and short C434.
- 2. Adjust the vertical sync with R331.
- 3. Remove the short C434.

Horizontal Amplitude and Centering Adjustment

- 1. Inject a cross-hatch pattern signal and set the Brightness Control (R589) and Contrast Control (R585) to their mechanical centers.
- Adjust R485 so that 14 blocks correspond to a width of 26cm.
- 3. Adjust R453 to center display horizontally.

Vertical Amplitude and Centering Adjustment

- Inject a cross-hatch pattern and set the Brightness Control (R585) to their mechanical centers.
- Adjust R353 so that 10 blocks correspond to a height of 18.5cm.
- Adjust R364 to center the display vertically.

Chrominance Adjustment

(Note: pin nos. in parenthesis indicate alternate 16-pin IC.)

- Inject a color bar pattern signal and adjust the secondary controls for normal viewing. Place SK3 (not used in CM8562, CM8762, 8CM542) in the off position.
- Connect an oscilloscope to pin 15 of IC502 and adjust S533 for minimum amplitude of the chrominance signal that is present on the various brightness steps of the luminance signal.
- 3. Short pins 9 (3) and 17 (11) of IC501.
- Adjust C567 to minimize the chroma as visible on the screen.
- 5. Remove the shorting clips from pins.

Comb Filter Adjustment (CM8505/CM8705/8CM505/8CM515/8CM643 ONLY)

- Inject a color bar pattern signal and place the Comb Filter Switch (SK3 in the on position).
- Connect an oscilloscope to the emitter of TS531 and adjust R523 and S515 for minimum amplitude of the chrominance signal. For optimum performance, repeat the adjustment.

Focus Adjustment

- Inject a cross-hatch pattern signal and set the Brightness Control (R589) to minimum and the Contrast control (R585) to maximum.
- 2. Adjust R732 for optimum focus.

X-Ray Protection Circuit Adjustment

- Inject a color bar pattern signal and set the Brightness and Contrast Controls to minimum.
- Connect a voltmeter between the wiper of R457 and ground.
- 3. Adjust R457 for a reading of 6.9V.

Note: The following adjustments need only be performed if the CRT has been replaced. Minor corrections for purity and convergence may be accomplished through the use of the Purity and Convergence Assembly located on the neck of the CRT.

Color Purity Adjustment (Refer to Figure 1)


- Loosen the yoke clamp screw and slide the yoke back away from the rubber wedges.
- Remove the rubber wedges (G) and slide the yoke forward until it rests firmly against the bell of the CRT
- 3. Tighten the yoke clamp screw slightly so that the yoke can still be moved with some friction.
- 4. Place the multi-pole Purity and Convergence Assembly in the position shown in Figure 1.
- Tighten screw (A) and turn securing ring (B) counterclockwise. Position the unit so that it faces in an East/West direction and degauss the instrument.
- 6. Turn on the power and inject a cross-hatch pattern signal. Allow a 10 minute warm-up period.
- Roughly adjust the static convergence, using tabs C and D.
- 8. Set the Vertical Centering Control (R364) to its mechanical center. Disconnect R723 and R724 to turn off the green and blue guns.

10. Inject a white pattern signal and move the deflection yoke to obtain a full red raster.

11. Turn on the green and blue guns by reconnecting R723 and R724. If a uniformly white raster does not appear, minor adjustments may be made by adjusting the purity rings (E).

12. Inject a cross-hatch pattern signal to ensure that the yoke is not tilted. If necessary, rotate the yoke to obtain a level raster.

13. Tighten screw F and adjust R364 for proper vertical centering. Proceed to the Static Convergence



Static Convergence Adjustment

Inject a crosshatch pattern signal and allow a 10 minute warm-up period.

Turn off the green gun by disconnecting R723. Turn locking ring (B) counterclockwise.

Slowly spread, and if necessary, rotate the 4-pole magnetic rings (C) to converge red and blue lines at the center of the screen.

Reconnect R723 to turn on the green gun and disconnect R724 to turn off the blue gun.

Slowly spread, and if necessary, rotate the 6-pole magnetic rings (D) to converge the red and green lines at the center of the screen.

Reconnect R724 to turn on the blue gun.

For optimum performance, repeat steps 1 through 6. Proceed to the Dynamic Convergence Adjust-

Dynamic Convergence Adjustment

Inject a cross-hatch pattern signal and turn off the green gun by disconnecting R723.

Tilt the yoke up and down to acheive the best convergence of the red and blue vertical lines at the 6 and 12 o'clock and the red and blue horizontal lines at the 3 and 9 o'clock positions (see Figure 2).

When the correct position has been found, place a rubber wedge between the CRT. If the yoke is tilted up, place wedge 1 as shown in Figure 3a; if it is tilted down, place wedge 1 as shown in Figure 4a.

Tilt the yoke to the left and right to find the point of best possible convergence of the red and blue lines

at the edges, top, and bottom of the screen as shown in Figure 5.

5. When the correct position is located, place wedges 2 and 3 as shown in Figure 3b or 4b.

6. Remove wedge 1 and place it in the final position as shown in Figure 3c or 4c. Reconnect resistor R723 to turn on the green gun.




Figure 2 — Tilt yoke up or down to converge Red and Blue vertical lines at 6 and 12 o'clock positions, and Blue horizontal lines at 3 and 9 o'clock positions.




Figure 5 - Tilt yoke left or right to converge Red and Blue horizontal lines at the 6 and 12 o'clock positions, and Red and Blue vertical lines at the 3 and 9 o'clock positions.

Note: A computer delivering RGB TTL output (IBM or Apple) should be used to properly test the RGB circuitry. However, if a computer is not available, the following procedure may be used. EXCEPTION: CM8562/CM8762/8CM542 does not accept Analog RGB or X-RGB signals.

ADJUSTMENT PROCEDURES (Continued)

RGB INTERFACE P.C. BOARD CHECKS FOR ALL MODELS (Except CM8562/CM8762/8CM542)

Late Production RGB Interface models are IBM Compatible only after Feb. 87.

Early Production models accept Apple (X-RGB) or IBM (RGB-1) prior to Feb. 2, 1987.

The purpose of this board is to accept RGB TTL signal inputs (RGB—I or X-RGB) and develope the R, G, and B signals in the monitor. By grounding the control input (Pin 1 of 8 pin Din Plug) the interface circuit will decode X-RGB to equal RGB-I signals in the monitor.

Interface P.C. Board Check

1. If either Apple (X-RGB) or IBM (RGB-I) signals are available as a TTL input the interface operation in the other signal mode may be checked. By grounding the control input on each color the other mode will appear. Pins 2, 3, 4, and 5 the 8 Pin Din Jack are high level when open. Use the cross reference chart for this cross color check.

2. To confirn proper operation of the RGB Interface Board, refer to the following truth table and ground the pins as shown. A voltmeter may be used to determine whether the output levels are high (1) or low (0). (Refer to schematic for pin nos.)

Another quick check may be done using a sine or square wave generator. A 1 to 3 kHz square wave (2Vp-p) may be injected into the pins of the DIN jack * IBM/APPLE switching line. (open=IBM; ground=APPLE) in the truth table. Color flashes should be visible on the screen which correspond to the pin or pins connected to the signal generator. Pin 2 should give red flashes, pin 3 green flashes, etc. when in the IBM mode. The colors will vary when pin 1 is grounded along with any of the others because the Apple colors are not the same as the IBM colors.

IBM TRUTH TABLE

		NPUT	s						OUT	PUTS				
(1)	DIN (B)	PLUG (G)			١.		IC27	PINS						
5	4	3	(R) 2	1	1	2	3	4	5	6	7	9	11	13
0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
0	0	0	1	1	1	1	1	0	0	0	0	0	0	0
0	0	1	0	1	0	0	0	1	1	1	0	0	0	1
0	0	1	1	1	1	1	1	0	1	0	0	0	0	1
0	1	0	0	,	0	0	0	0	0	0	1	1	1	0
0	1	0	1	1	1	1	1	0	0	0	1	1	1	0
0	1	1	0	1	0	0	0	1	1	1	1	1	1	1
0	1	1	1	1	1	1	ï	1	1	1	1	1	1	1
1	0	0	0	1	0	0	0	0	0	0	0	0	0	0
1	0	0	1	1	1	1	1	0	0	0	0	0	0	0
1	0	1	0	1	0	0	0	1	1	1	0	0	0	1
1	0	1	1	1	1	1	1	1	1	1	0	o	0	1
,	1	0	0	1	0	0	0	0	0	0	1	1	1	0
١,	1	0	1	1	1	1	1	0	0	0	1	1	1	0
١,	1	1	0	1	0	0	0	1	1	1	1	1	1	1
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

IBM is a registered trademark of International **Business Machines**

APPLE TRUTH TABLE

	1	NPUT	S						OUT	PUTS				
	DIN	PLUG	PINS					IC27	2 PINS	;			IC27	1 PINS
(1)	(B)	(G)	(R)	•										
6	4	3	2	1	1	2	3	4	5	6	7	9	11	13
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0	0	0	1	0	1	0	0	1	0	0	1	0	0	0
0	0	1	0	0	0	1	0	0	0	0	0	1	0	1
0	0	1	1	0	1	1	0	1	0	0	1	1	0	1
0	1	0	0	0	0	0	0	0	1	0	0	0	1	0
0	1	0	1	0	1	0	0	1	1	0	1	0	1	0
0	1	1	0	0	0	1	0	0	1	0	0	1	1	1
0	1	1	1	0	1	1	0	1	1	0	1	1	1	1
1	0	0	0	0	0	0	1	0	0	1	0	0	0	0
١	0	0	1	0	1	0	1	1	0	1	1	o	0	0
١	0	1	0	0	0	1	1	0	0	1	0	1	0	1
1	0	1	1	0	1	1	1	1	0	1	1	1	0	1
1	1	0	0	0	0	0	1	0	1	1	0	0	1	0
١ ا	1	0	1	0	1	0	1	1	1	1	1	0	1	0
١ ا	1	1	0	0	0	1	1	0	1	1	0	1	1	1
١,	1	1	1	0	1	1	1	1	1	1	1	1	1	1

RGB-TTL INPUTS (8 PIN DIN) Color Decoding Chart

Levels shown are with monitor driven by computer.

	Pin	
APPLE X-RGB	5 4 3 2	IBM RGB-I
BLACK	0000	BLACK
MAGENTA	0001	RED
DARK BLUE	0 0 1 0	GREEN
PURPLE	0 0 1 1	BROWN
DARK GREEN	0 1 0 0	BLUE
GREY 1	0 1 0 1	MAGENTA
MIDDLE BLUE	0 1 1 0	CYAN
LIGHT BLUE	0 1 1 1	WHITE
BROWN	1000	GREY
ORANGE	1 0 0 1	LIGHT RED
GREY 2	1 0 1 0	LIGHT GREEN
PINK	1 0 1 1	LIGHT YELLOW
GREEN	1 1 0 0	LIGHT BLUE
YELLOW	1 1 0 1	LIGHT MAGENTA
AQUA	1 1 1 0	LIGHT CYAN
WHITE	1 1 1 1	INTENSIFIED WHITE

TTL Levels

Low (0) = Zero to .8 volts

Pin 1 is Apple/IBM Control Line

Low (0) = Apple, High (1) = IBM Colors

High (1) = 2.4 to 5 volts

Apple is a registered trademark of Apple Computers


ADJUSTMENT PROCEDURES (Continued)


RGB 8 and 6 Pin DIN Sockets

PIN ASSIGNMENTS

PIN NO.	TTL INPUT 8 PIN SIGNAL	ANALOG 6 PIN SIGNAL
* 1	IBM Open/Apple Gnd.	Green
2	Red	Horiz. Sync
3	Green	Ground
4	Blue	Red
5	Intensity	Blue
6	Ground	Vert. Sync
7	Horiz. Sync	
8	Vert. Sync	


When using these sockets before connecting the equipment, place the RGB/Composite Switch in the RGB position.






INTERCONNECT DIAGRAM

Note: To Remove Power Board Depress Locking Clip Located on Bottom of Cabinet Beneath Power Board.



WAVEFORMS



44Vp-p

20μS

30.

64Vp-p


20μ**S**

1. WAVEFORMS TAKEN UNDER THE CONDITIONS SPECI-FIED THE SCHEMATIC NOTES.
2. SWEEP/TIME CM SETTINGS ARE SHOWN JUST BELOW PHOTOS. ALL PHOTOS WERE TAKEN WITH THE SWEEP TIME CONTROLS IN THE CALIBRATED POSITION. HORIZONTAL POSITIONING OF THE WAVEFORMS WAS ADJUSTED FOR MAXIMUM CLARITY.


^{*}Not used in CM8562/CM8762/8CM542

8CM505/8CM515/8CM643/CM8505/CM8705 MAIN P.C. BOARD (viewed from component side)

NOTE: When IC501 has 16 Pin IC the following parts are not used; R550, R559, R561 & C568



INTERFACE SCHEMATIC DIAGRAM (Late Production Version)



SCHEMATICS NOTES: UNLESS OTHERWISE SPECIFIED:

- ALL VOLTAGES AND WAVEFORMS TAKEN UNDER THE FOL-LOWING CONDITIONS
 - LINE VOLTAGE MAINTAINED AT 120VAC, 60Hz VIA AN ISO-LATION TRANSFORMER.

- CUSTOMER CONTROLS SET AS FOLLOWS:
 VOLUME CONTROL (R316) SET TO MINIMUM.
- COLOR CONTROL (R581) SET FOR 8.75VDC WIPER TO GROUND.
- CONTRAST CONTROL (R585) SET FOR 8.7VDC WIPER TO GROUND
- BRIGHTNESS CONTROL (R589) SET FOR 5VDC WIPER TO GROUND.
- HUE CONTROL (R565) SET FOR 6VDC WIPER TO GROUND
- SK2 IN CVBS POSITION.
- SK3, SK4 & SK5 OFF

E.P. REFERS TO EARLY PRODUCTION L.P. REFERS TO LATE PRODUCTION

- **VOLTAGES AND WAVEFORMS WERE TAKEN USING A 10 BAR** GATED RAINBOW PATTERN SIGNAL SET TO DELIVER CHROMA BARS OF .5Vp-p AT THE VIDEO IN JACK.
- ALL VOLTAGES ARE POSITIVE DC WITH RESPECT TO GROUND. BE IT THE ISOLATED (SIGNAL) GROUND OR THE AC (HOT) GROUND WHICHEVER IS PRESENT IN THAT AREA OF CIRCUITRY.
- VOLTAGES MAY VARY DUE TO NORMAL PRODUCTION TOL-
- ERENCES. VOLTAGE SOURCES ARE ALSO NOMINAL.
 RESISTORS ARE ALL 5%, ¼W, CARBON FILM EXCEPT FOR
 SOME UNIQUE PARTS. REFER TO REPLACEMENT PARTS LIST.
- CAPACITOR VALUES ARE IN MICROFARADS & PICOFARADS. REFER TO SCHEMATIC DIAGRAM FOR VALUES AND VOLT-AGES EXCEPT FOR UNIQUE PARTS SHOWN IN REPLACEMENT PARTS LIST.

WARNING

Critical components having special safety characteristics are identified with an S by the Ref. No. in the parts list and enclosed within a broken line* along with the safety symbol on the schematics or exploded views.


Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from the N.A.P. Consumer Electronics Corp. NAPCEC assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.


* Broken line: 🕳




6523-12




8CM505/8CM515/8CM643/CM8505/CM8705 RGB INTERFACE P.C. BOARD (Early Production Version) (viewed from component side)




INTERFACE P.C. BOARD (Late Production Versions) (viewed from component side)



POWER SUPPLY P.C. BOARD (Late Production Version) (viewed from component side)




POWER SUPPLY P.C. BOARD (Early Production Version)
(viewed from component side)




8CM542/CM8562/CM8762 MAIN P.C. BOARD (viewed from component side)

NOTE: When IC501 has 16 Pin IC the following parts are not used; R550, R559, R561 & C568



IC501 ALTERNATE 16 PIN IC



SCHEMATIC NOTES UNLESS OTHERWISE SPECIFIED

- ALL VOLTAGES AND WAVEFORMS TAKEN UNDER THE FOL-LOWING CONDITIONS:
 - LINE VOLTAGE MAINTAINED AT 120VAC, 60Hz VIA AN ISO-LATION TRANSFORMER.

CUSTOMER CONTROLS SET AS FOLLOWS

- VOLUME CONTROL (R316) SET TO MINIMUM. COLOR CONTROL (R581) SET FOR 8.75VDC WIPER TO **GROUND**
- CONTRAST CONTROL (R585) SET FOR 8.7VDC WIPER TO **GROUND**
- BRIGHTNESS CONTROL (R589) SET FOR 5VDC WIPER TO GROUND
- HUE CONTROL (R565) SET FOR 6VDC WIPER TO GROUND.
- SK2 IN CVBS POSITION.
- SK3, SK4 & SK5 OFF

E.P. REFERS TO EARLY PRODUCTION L.P. REFERS TO LATE PRODUCTION

- **VOLTAGES AND WAVEFORMS WERE TAKEN USING A 10 BAR** GATED RAINBOW PATTERN SIGNAL SET TO DELIVER CHROMA BARS OF .5Vp-p AT THE VIDEO IN JACK.
- ALL VOLTAGES ARE POSITIVE DC WITH RESPECT TO GROUND. BE IT THE ISOLATED (SIGNAL) GROUND OR THE AC (HOT) GROUND WHICHEVER IS PRESENT IN THAT AREA OF **CIRCUITRY**
- VOLTAGES MAY VARY DUE TO NORMAL PRODUCTION TOL-
- ERENCES. VOLTAGE SOURCES ARE ALSO NOMINAL.
 RESISTORS ARE ALL 5%, ¼W, CARBON FILM EXCEPT FOR
 SOME UNIQUE PARTS. REFER TO REPLACEMENT PARTS LIST.
- CAPACITOR VALUES ARE IN MICROFARADS & PICOFARADS REFER TO SCHEMATIC DIAGRAM FOR VALUES AND VOLT-AGES EXCEPT FOR UNIQUE PARTS SHOWN IN REPLACEMENT PARTS LIST.

WARNING

Critical components having special safety characteristics are identified with an S by the Ref. No. in the parts list and enclosed within a broken line* along with the safety symbol on the schematics or exploded views.

Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from the N.A.P. Consumer Electronics Corp. NAPCEC assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.

Broken line: _____.

8CM542/CM8562/CM8762 SCHEMATIC DIAGRAM

6523-21


(Parts List - Pgs. 23, 24, 25)

6523-20

CAUTION: USE A SEPARATE ISOLATION TRANSFORMER \$\frac{1}{2}\$ INDICATES "HOT" GROUND. FOR THIS UNIT WHEN SERVICING.

≟ INDICATES ISOLATED SIGNAL GROUND.

NOTE: IC501 Alternate 16 Pin IC, See Insert Page 18



6523-22

6523-23

38 671 A12

38 359 B12 (544)

8CM542/CM8562/CM8762 RGB INTERFACE P.C. BOARD (Early Production Version)

(viewed from component side)

CRT P.C. BOARD (viewed from component side)

5772 — — R722

•1 29 39 49 59 M6

ELECTRICAL REPLACEMENT PARTS LIST TO ENSURE OPTIMUM PERFORMANCE AND RELIABILITY

ALWAYS USE GENUINE FACTORY REPLACEMENT PARTS WARNING

(Schem. - Pgs. 11, 12, 13/19, 20, 21)

A on the schematics or exploded views.

Use of substitute replacement parts which do not have the Broken line: ____. ___. same specified safety characteristics may create shock, fire, or other hazards.

are identified with an S by the Ref. No. in the parts list and fied or altered without written permission from the N.A.P. enclosed within a broken line* along with the safety symbol Consumer Electronics Corp. NAPCEC assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.

CM8505/CM8562/CM8705/CM8762/8CM505/8CM643/8CM515/8CM542 REPLACEMENT PARTS LIST

	112127	OLIVILIA I 7	•••			
Ref.	Description	Part No.		Ref.	Description	Part No.
COILS & TRA	NSFORMERS			SISTORS		
S S102	Line Choke	3693400001	(uı	nless otherwi	se specified, all are 5%, ¼W, Metal Fi	
S S104	Degaussing Coil	3693100005		C718	.01uF., 500V, Ceramic	2509040919
S131	10uH Coil	3618271360		R103	2.2 ohm, 7W, Wire Wound	2401440096
S136	2uH, Coil (L.P.)	5699000032	S	R104	Dual PTC	4H11640035
S S348 S465	Deflection Yoke	Part of CRT 3290000013		R121	390k, Carbon Film	2302861029 2301922235
S472	7.5uH Coil Coil	3618271363	c	R133 R232	22k, 2W, Metal Film 4.7 ohm	4H11130499
S473	720uH Coil	3618271362	3	R235	15 ohm	2302681595
S474	Coil	3618271364	S	R324	4.7 ohm	2302684785
S491	100uH Coil	3618271361		R346	4.7 ohm	2302684785
S493	Coil	3618271358	·	R433	3.3k	2302823325
S494	100uH Coil	3618271361		R443	8.2 ohm	2302688285
S515	3.58MHz Coil (CM8505/CM8705/	3618271369		R455	100 ohm	2302681015
	8CM505/8CM515/8CM643)			R458	10k	2302821035
S533	3.58MHz Coil	3618271342		R461	1k, 2W, Metal Film	2394061025
S534	Delay Line	1606770123	S	R462	8.2 ohm	2302688285
S536	39uH Coil	3618271367		R465	3.3 ohm, 2W, Metal Film	2394063395
S544 S555	6.8uH Coil 27uH Coil	3618271377		R469	12 ohm, 5W, Wire Wound	2401440102
S601	2.2uH Coil	3618271379 3618271378	s	R472	1k, 2W, Metal Film	2394061025
S602	2.2uH Coil	3618271378	3	R474 R475	5.6 ohm 15k, 2W, Metal Film	2302685685 2302861027
S603	2.2uH Coil	3618271378	S	R484	1.5 ohm	2302861585
S638	120uH Coil	3618271358		R512	8.2 ohm	2302688285
S717	8.2uH Coil	3618271366		R537	4.7 ohm	2302684785
S718	10uH Coil	3618271360	_	R562	4.7 ohm	2302684785
S721	10uH Coil	3618271360	S		4.7 ohm	2302684785
S722	4.7uH Coil	3618271359		R636	680 ohm, 2W, Metal Film	2394066815
S723	4.7uH Coil	3618271359	S	R642	8.2 ohm	2302688285
S724	4.7uH Coil	3618271359		R714	3.9k, 3W, Metal Film	2302861028
S T101	Transformer	3090200003		R715	3.9k, 3W, Metal Film	2302861028
T401 S T402	Horizontal Drive Transformer	3293000001		R716	3.9k, 3W, Metal Film	2302861028
1515	Output Transformer Delay Line (CM8505/CM8705/	3291000006		R721	1M, ½W, Carbon Composition	2394041055
1313	8CM505/(CM515)	1606770121		R722 R723	470 ohm, ½W, Carbon Composition	
	0C1413037 (C141313)			R724	470 ohm, ½W, Carbon Composition 470 ohm, ½W, Carbon Composition	
CAPACITORS				R725	330k, ½W, Carbon Composition	2302123715
S C102	.22uF., 125VAC, Polyester Film	2602320550		R728	1.5k, ½W, Carbon Composition	2302641525
S C103	.0047uF., 125VAC, Ceramic	2602320532		R731	1.5k, ½W, Carbon Composition	2302641525
S C104	.0047uF., 125VAC, Ceramic	2602320532			•	
S C106	.047uF., 400V, Polyester Film	2506564739	C	ONTROLS &		
S C107	.0022uF., 1kV, Ceramic	2509041035		C567	Trimmer Capacitor, 27pF.	2602320548
S C108	.0022uF., 1kV, Ceramic	2509041035		R114	Trimpot, 1k	2291010058
S C109 S C110	.0022uF., 1kV, Ceramic	2509041035		R316	Volume Control, 100k	2204290729
S C110 S C111	.0022uF., 1kV, Ceramic	2509041035		R331 R338	Vertical Frequency Control, 47k	2291010053
S C112	.22uF., 250V, Polyester Film (L.P.) 220uF., 50V, Electrolytic	2506552249 2509040485		R353	Vertical Linearity Control, 100k Vertical Size Control, 220k	2291010060 2204290761
C132	.0047uF., 630V, Polyester Film	2509040712		R364	Vertical Centering Control, 10k	2291010086
C136	470pF., 2KV (E.P.)	2602320547		R437	Horizontal Frequency Control, 22k	2204291040
C141	220pF., 500V, Ceramic	2602320546		R453	Horizontal Centering Control, 10k	2291010086
C142	220pF., 500V, Ceramic	2602320546		R457	Trimpot, 22k (E.P.)	2204692232
C143	220pF., 500V, Ceramic	2602320546		R457	Trimpot, 47k (L.P.)	2302124732
C443	.022uF., 50V	2602320529		R485	Horizontal Size Control, 10k	2291010086
S C467	.0082uF., 1.5kV, Polyester Film	2602320549		R496	Pin Cushion, 4.7k (8CM643)	2291010052
S C468	.022uF., 400V, Polypropylene	2602320597		R523	Trimpot, 330 ohm (CM8505/	2204290732
S C470	470pF., Ceramic	2602320547			CM8705/8CM515/8CM515/	
C471	.47uF., 250V, Polyester Film	2602320551		DE 42	8CM643)	2204200727
C471	(8CM515/CM8562/8CM643) .68uF., 10%, 250V, Polyester Film	2509040718		R542 R565	Sharpness Control, 500 ohm	2204290727
0471	(CM8505/CM8705/8CM505)	2303040718		R581	Trimpot, 10k Color Control, 10k	2204290728 2204290728
C473	4.7uF., 50V, Bipolar	2701740675		R585	Contrast Control, 10k	2204290728
C508	56pF., 2%, 100V, Ceramic	2602320544		R589	Brightness Control, 10k	2204290728
	(CM8505/CM8705/8CM505/			R598	Sub Brightness, 10k (8CM643)	2203011032
	8CM515/8CM643)			R605	Trimpot, 1k	2204290725
C535	120pF., 50V, Ceramic	2602320552			Trimpot, 1k	2204290725
C554	39PF., 5%, 50%, Ceramic	2509041033		R704	Trimpot, 4.7k	2291010052
C555	27pF., 5%, 50V, Ceramic	2509041032		R705	Trimpot, 4.7k	2291010052

6523-24

Description

8CM505/8CM515/8CM643)

Ref.

Ref.	Description	Part No.	nei.	Description	
CONTROLS 8	SWITCHES (Continued)		SEMICO	NDUCTORS (Continued)	
		4H10010236	TS531	NPN, Silicon (CM8505/CM8706/	6103700001
R706 R727	Trimpot, 4.7k Potentiometer, 5M	2204290726	10001	8CM505/8CM515/8CM643)	
S R732	Focus Control, 59M	2204290730	TS544	NPN, Silicon	6103700001
S SK1	Power Switch	1606780548	TS552	NPN, Silicon (CM8505/CM8705/	6103700001
SK2	RGB/CVBS Switch	1606780549		8CM505/8CM515/8CM643) NPN, Silicon (CM8505/CM8705/	6103700001
SK3	Comb Filter Switch (CM8505/	1606780549	TS604	8CM505)	0103700001
01/4	CM8705/8CM505/8CM515)	1606780549	TS604	NPN, Silicon (8CM515/CM8562/	4H13041594
SK4 SK5	Green Switch VCR Switch	1606780549	10004	CM8762/8CM542)	
			TS605	NPN, Silicon (CM8505/CM8705/	6103700001
SEMICONDU		E202110001		8CM505)	4H13041594
S IC101	Optic Coupler IC Inverter IC (CM8562)	5303110001 6193100140	TS605	NPN, Silicon (8CM515/CM8562/ CM8762/8CM542)	4013041334
IC251 IC252	Inverter IC (CM8562)	6193100140	TS606	NPN, Silicon (CM8505/C8705/	6103700001
IC271	Inverter IC (CM8505/CM8705/	6121970001	10000	8CM505)	
	8CM505/8CM515/8CM643)		TS606	NPN, Silicon (8CM515/CM8562/	4H13041594
IC272	Decoder / Matrix IC	6193100070		CM8762/8CM542)	6104350002
	(CM8505/CM8705/8CM505/ 8CM515/8CM643)		TS633 TS635	NPN, Silicon NPN, Silicon	6105270002
IC273	AND Gate IC (CM8505/8CM505/	6121990001	TS641	NPN, Silicon	6103720002
10270	8CM515/8CM643)		TS711	NPN, Silicon	6104390001
IC301	Audio Amp IC	6192001060	TS712	NPN, Silicon	6104390001
IC302	Vertical Signal Processor IC	6123300289 6122890001	TS713	NPN, Silicon	6104390001 5391200341
IC401 IC402	Exclusive OR Gate IC Horizontal Signal Processor IC	6123300330	S D107 S D108	Diode Diode	5391200341
IC402	Voltage Stabilizer IC	6192140331	S D108	Diode	5391200341
IC501	Video Processor IC (28 Pin)	6123300332	S D110	Diode	5391200341
IC501	Video Processor IC (16 Pin)	6123300374	D111	Diode (L.P.)	5302250240
IC502	Video Processor/Video Amp IC	6192080240 6105000004	D115	Zener Diode	5301570629 5301811002
TS117 TS121	NPN, Silicon NPN, Silicon	6190004040	D121	Diode Diode	5301811002
TS132	NPN, Silicon	6190002200	D125 D126	Diode	5301811001
TS152	Thyristor	6191400010	D127	Diode	5301811001
TS211	NPN, Silicon (CM8505/CM8705/	6103700001	D128	Zener Diode	4H13030862
T0040	8CM505/8CM515/8CM643)	6103700001	D129	Zener Diode, 2.4V	4H13031253
TS212	NPN, Silicon (CM8505/CM8705/ 8CM505/8CM515/8CM643)	0103700001	D131	Diode Diode	5301811002 4H13031393
TS213	NPN, Silicon (CM8505/CM8705/	6103700001	D133 D141	Diode	4H13032833
.02.0	8CM505/8CM515/8CM643)		D142	Diode	4H13031607
TS217	NPN, Silicon (CM8505/CM8705/	6103700001	D143	Diode	5H13031971
TC240	8CM505/8CM515/8CM643) NPN, Silicon (CM8505/CM8705/	6103700001	D151	Diode	5302681002
TS218	8CM505/8CM515/8CM643)	0103700001	D152	Diode Diode (CM8505/CM8705/	4H13031024 5301811002
TS219	NPN, Silicon (CM8505/CM8705/	6103700001	D221	8CM505/8CM515/8CM643)	3301011002
	8CM505/8CM515/8CM643)		D222	Diode (CM8505/CM8705/	5301811002
TS228	NPN, Silicon (CM8505/CM8705/	6103700001		8CM505/8CM515/8CM643)	
TS233	8CM505/8CM515/8CM643) PNP, Silicon (CM8505/CM8705/	6190101480	D223	Diode (CM8505/CM8705/	5301811002
13233	8CM505/8CM515/8CM643)	0130101400	D234	8CM505/8CM515/8CM643) Zener Diode	4H13034167
TS235	NPN, Silicon	6190004860	D262	Diode (CM8562/CM8762/	5801811002
TS275	NPN, Silicon (CM8562/CM8762/	6104350002	2-0-	8CM542)	
TC207	8CM542) NPN, Silicon (CM8562/CM8762/	6102700001	D263	Diode (CM8562/CM8762/	5801811002
TS287	8CM542)	0103700001	D264	8CM542) Diode (CM8562 / CM8762 /	5801811002
TS288	NPN, Silicon (CM8562/CM8762/	6103700001	D264	8CM542)	5601611002
	8CM542)		D265	Diode (CM8562/CM8762/	5801811002
TS289	NPN, Silicon (CM8562/CM8762/	6103700001		8CM542)	
TS291	8CM542) NPN, Silicon (CM8505/CM8705/	6103700001	D266	Diode (CM8562/CM8762/	5801811002
13231	8CM505/8CM515/8CM643)	0103700001	D276	8CM542) Diode (CM8562 / CM8762 /	5801811002
TS292	NPN, Silicon (CM8505/CM8705/	6104350002	D276	8CM542)	3801811002
	8CM505/8CM515/8CM643)		D277	Diode (CM8562/CM8762/	5801811002
TS293	NPN, Silicon (CM8505/CM8705/	6103700001		8CM542)	
TS298	8CM505/8CM515/8CM643) NPN, Silicon (CM8505/CM8705/	6103700001	D278	Diode (CM8562/CM8762/	5801811002
10230	8CM505/8CM515/8CM643)	0.0070000.	D325	8CM542) Green LED	5392100470
TS299	NPN, Silicon (CM8505/CM8705/	6104350002	D323	Diode	5301811002
T0067	8CM505/8CM515/8CM643)	0400404400	D337	Diode	5301811002
TS367 TS368	PNP, Silicon NPN, Silicon	6190101480 6103680002	D346	Diode	5301711002
TS406	NPN, Silicon (CM8505/CM8705/	6104350002	D412	Diode	5301811002
	8CM505/8CM515/8CM643)		D432 D433	Zener Diode, 4.7V Diode	5390150479 5301811002
TS413	NPN, Silicon	6104350002	D455	Diode	5302681002
TS418	NPN, Silicon	6103700001	D457	Diode	5301811002
TS419 TS439	NPN, Silicon NPN, Silicon	6103700001 6104350002	D461	Diode	4H13031607
TS461	NPN, Silicon	6105350002	D465 D467	Diode Diode	4H13031607
TS467	NPN, Silicon	6104330001	D467	Diode Diode	5302591001 5302601002
TS474	PNP, Silicon	6104380001	2 100		000100.002
TS478 TS508	NPN, Silicon NPN, Silicon	6104350002 6103700001			
TS508	NPN, Silicon	6104350002			
TS514	NPN, Silicon	6103700001			
TS517	NPN, Silicon (CM8505/CM8705/	6103700001			
TCF10	8CM505/8CM515/8CM643) NPN, Silicon (CM8505/CM8705/	6102700001			
TS518	8CM505/8CM515/8CM643)	0103700001			

Part No.

Part No.

Description

SEMICONDUCTORS (Continued)		Ref.	Description	Part No.	Ref.	Description	Part No.
D571		SEMICON	DUCTORS (Continued)			MISCELLANEOUS (Continued)	
D572 Diode							1491030002
Diode		D572	Diode	5301811002		Cabinet Foot, 4 used (8CM505/	1491030003
Diode							1491320214
Decid				5301811002			
Diode				5301811002			
D603				5301811002			1492180012
D604 Diode				5301811002			
D605 Diode 5301811002 Text Plate (8CM505/8CM515) 1591060004				5301811002			
D714				5301811002			
D715							
D716 Diode							1494200066
MISCELLANEOUS							
MISCELLANEOUS Tuse, 3A 1813900214 (CM8562/CM8762/8CM542) 1494200074 (CM8562/CM8762/8CM542) 1494200067 1494200067 1494200067 1494200067 1494200067 1494200067 1494200067 1494200067 1494200067 1494200067 1494200067 1494200068 1494		D716	Diode	5302681002			1494200074
S L101 Fuse, 3A Fuse Holder (2 used) 1813900214 1035300932 (CM8562/CM8762/8CM542) Pushbutton Knob (VCR SW 1494200067 S B100 CRT w/Deflection Yoke (CM8505/CM8705) A34EAJ00X A34EAJ00X Pushbutton Knob (RGB/CVBS 1494200068 S B100 CRT w/Deflection Yoke (8CM505) CRT w/Deflection Yoke (8CM542/8CM643) A34EAJ10X B2971B55 Green (2 used) CM8705/8CM505/8CM505/8CM505/ 4613990214 S B100 CRT w/Deflection Yoke (8CM542/8CM643) M34EAQ10X B2971B55 High Voltage Cable (CM8562/ CM8762/8CM542) 4613990214 S CRT Socket (CM8562/CM8762) 1892250011 S088350051 Focus Cable Control Extender Rod (4 used) 1191000039 119100039 S Crystal RCA Jack (2 used) 1813930160 1847290001 Owner's Manual (8CM505) 1847290001 1847590001 RCM8705/8CM505/8CM515/ 8CM643) RCM8705/8CM505/8CM515/ 8CM643) Owner's Manual (CM8705) 1850090001 185000001 B Pin DIN Socket Cabinet (CM8505) 1492100002 1492100002 Owner's Manual (CM8762) 1853150001 1852560001							
S							1494200074
S B100 CRT w/Deflection Yoke (CM8505/CM8705) A34EAJ00X Pushbutton Knob (RGB/CVBS, Pushbutton Knob (RGB/CVBS)		L101					
CM8505/CM8705							1494200067
S B100 CRT w/Deflection Yoke (8CM505) A34EAJ10X Green (2 used) S B100 CRT w/Deflection Yoke (8CM515) M34EAQ00X High Voltage Cable (CM8505/ 4613990214 S B100 CRT w/Deflection Yoke (8CM543) E2971855 CM8705/8CM505/8CM515/ 8CM643) S B100 CRT w/Deflection Yoke (CM8562/CM8762) M34EAQ10X High Voltage Cable (CM8562/ 4613990221 C (CM8562/CM8762) CM8762/8CM542) CM8762/8CM542) 4613990221 S CRT Socket (CM8562/CM8762) 1892250011 Focus Cable (CM8562/CM8762) 4613990213 S323 Speaker (Crystal (CM8505) 5699000028 Owner's Manual (CM8505) 1847290001 BCA Jack (2 used) (CM8505/CM515/CM8705/8CM505/8CM515/CM8705/8CM505/8CM515/CM8705/8CM505/8CM515/ABCM505/8CM515/ABCM505/8CM515/ABCM505/ABCM505/8CM515/ABCM505/	S	B100		A34EAJ00X			
S B100 CRT w/Deflection Yoke (8CM515) M34EAQ00X E2971B55 High Voltage Cable (CM8505/ 8CM505/8CM505/8CM505/8CM505/8CM515/ 8CM643) 4613990214 S B100 CRT w/Deflection Yoke (8CM542) K2971B55 CM8705/8CM505/8CM505/8CM515/ 8CM643) 4613990221 S B100 CRT w/Deflection Yoke (8CM542) M34EAQ10X High Voltage Cable (CM8562/ 4613990221 4613990221 C CM8762/8CM542) CM8762/8CM542) 4613990221 4613990221 S CRT Socket 1892250011 Focus Cable 4613990213 S Speaker 5808350051 Control Extender Rod (4 used) 1191000039 Crystal 5699000028 Owner's Manual (8CM505) 1847290001 R CA Jack (2 used) 1813930160 Owner's Manual (8CM505) 1847540001 G Pin DIN Socket (CM8505/ 1814521073 Owner's Manual (8CM643) 1850090001 R CM643) 8 Pin DIN Socket 1814521072 Owner's Manual (CM8762) 1853150001 R CA Jack (2 used) 1892100002 Owner's Manual (CM8762) 1848180001 C Cabinet (CM8505) 1492100003 Owner's Manual (CM8562) 1848180001	_						1494200068
S B100	_						
S B100 CRT w/Deflection Yoke (CM8562/CM8762) M34EAQ10X High Voltage Cable (CM8562/ 4613990221 CM8762/8CM542) CM8762/8CM542) S CRT Socket 1892250011 Focus Cable 4613990213 S S S S S S S S S							4613990214
CM8562/CM8762 CM8762/8CM542 CM8762/8CM542 S CRT Socket 1892250011 Focus Cable 4613990213 S323 Speaker 5808350051 Control Extender Rod (4 used) 1191000039 Crystal 5699000028 Owner's Manual (CM8505) IB47290001 RCA Jack (2 used) 1813930160 Owner's Manual (8CM505) IB47540001 6 Pin DIN Socket (CM8505/ 1814521073 Owner's Manual (8CM515) IB47550001 CM8705/8CM505/8CM515/ 8CM643) Owner's Manual (8CM643) IB50090001 R Pin DIN Socket 1814521072 Owner's Manual (CM8705) IB53160001 Cabinet (CM8505) 1492100002 Owner's Manual (CM8762) IB53150001 Cabinet (8CM505) 1492100003 Owner's Manual (BCM542) IB52560001			(8CM542/8CM643)	E2971B55		8CM643)	
S323 Speaker 5808350051 Control Extender Rod (4 used) 1191000039 1567 Crystal 5699000028 Owner's Manual (CM8505) IB47290001 RCA Jack (2 used) 1813930160 Owner's Manual (8CM505) IB47540001 6 Pin DIN Socket (CM8505/ 1814521073 Owner's Manual (8CM643) IB50090001 8 CM643) B Pin DIN Socket 1814521072 Owner's Manual (CM8705) IB53160001 8 Pin DIN Socket 1814521072 Owner's Manual (CM8762) IB53150001 Cabinet (CM8505) 1492100002 Owner's Manual (CM8562) IB48180001 Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001	S	B100		M34EAQ10X		CM8762 / 8CM542)	
1567 Crystal 569900028 Owner's Manual (CM8505) IB47290001 RCA Jack (2 used) 1813930160 Owner's Manual (8CM505) IB47540001 6 Pin DIN Socket (CM8505/ 1814521073 Owner's Manual (8CM515) IB47550001 CM8705/8CM505/8CM515/ Owner's Manual (8CM643) IB50090001 8 Pin DIN Socket 1814521072 Owner's Manual (CM8705) IB53160001 Cabinet (CM8505) 1492100002 Owner's Manual (CM8562) IB48180001 Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001	S		CRT Socket	1892250011			
RCA Jack (2 used) 1813930160 Owner's Manual (8CM505) IB47540001 6 Pin DIN Socket (CM8505/ 1814521073 Owner's Manual (8CM515) IB47550001 CM8705/8CM505/8CM515/ Owner's Manual (8CM643) IB50090001 8 CM643) Owner's Manual (CM8705) IB53160001 8 Pin DIN Socket 1814521072 Owner's Manual (CM8762) IB53150001 Cabinet (CM8505) 1492100002 Owner's Manual (CM8562) IB48180001 Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001			Speaker	5808350051			
6 Pin DIN Socket (CM8505 / 1814521073 Owner's Manual (8CM515) IB47550001 CM8705/8CM505/8CM515 Owner's Manual (8CM643) IB50090001 8 CM643) Owner's Manual (CM8705) IB53160001 8 Pin DIN Socket 1814521072 Owner's Manual (CM8762) IB53150001 Cabinet (CM8505) 1492100002 Owner's Manual (CM8562) IB48180001 Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001		1567	Crystal	5699000028			
CM8705/8CM505/8CM515/ Owner's Manual (8CM643) IB50090001 8CM643) Owner's Manual (CM8705) IB53160001 8 Pin DIN Socket 1814521072 Owner's Manual (CM8762) IB53150001 Cabinet (CM8505) 1492100002 Owner's Manual (CM8562) IB48180001 Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001			RCA Jack (2 used)	1813930160			
8CM643) Owner's Manual (CM8705) IB53160001 8 Pin DIN Socket 1814521072 Owner's Manual (CM8762) IB53150001 Cabinet (CM8505) 1492100002 Owner's Manual (CM8562) IB48180001 Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001			6 Pin DIN Socket (CM8505/	1814521073			
8 Pin DIN Socket 1814521072 Owner's Manual (CM8762) IB53150001 Cabinet (CM8505) 1492100002 Owner's Manual (CM8562) IB48180001 Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001			CM8705/8CM505/8CM515/				
Cabinet (CM8505) 1492100002 Owner's Manual (CM8562) IB48180001 Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001			8CM643)				
Cabinet (8CM505) 1492100003 Owner's Manual (8CM542) IB52560001				1814521072			
140210000				1492100002			
			Cabinet (8CM505)	1492100003		Owner's Manual (8CM542)	IB52560001
			Cabinet (8CM515, 8CM643)	1492100004			
Cabinet (8CM542) 1492900004			Cabinet (8CM542)				
Cabinet (CM8562) 1492100005			Cabinet (CM8562)	1492100005			

NAPCEC SAFETY GUIDELINES FOR THE PROFESSIONAL SERVICE TECHNICIAN

Safety Checks

After the original service problem has been corrected, a complete safety check should be made. Be sure to check over the entire set, not just the areas where you have worked. Some previous servicer may have left an unsafe condition, which could be unknowingly passed on to your customer. Be sure to check all of the following:

Fire and Shock Hazard

- Be sure all components are positioned in such as way as to avoid the
 possibility of adjacent component shorts. This is especially important
 on those chassis which are transported to and from the service shop.
- Never release a repaired receiver unless all protective devices such as insulators, barriers, covers, strain reliefs, and other hardware have been installed according to the original design.
- Soldering and wiring must be inspected to locate possible cold solder joints, solder splashes, sharp solder points, frayed leads, pinched leads, or damaged insulation (including ac cord). Be certain to remove loose solder balls and all other loose foreign particles.
- Check across-the-line components and other components for physical evidence of damage or deterioration and replace if necessary. Follow original layout, lead length and dress.
- No lead or component should touch a receiving tube or a resistor rated at 1 watt or more. Lead tension around protruding metal surfaces or edges must be avoided.
- 6. Critical components having special safety characteristics are identified with an S by the Ref. No. in the parts list and enclosed within a broken line* along with the safety symbol on the schematics. Replacement parts without the same safety characteristics may create shock, fire or other hazards.
- 7. When servicing any receiver, always use a separate isolation transformer for the chassis. Failure to use a separate isolation transformer may expose you to possible shock hazard, and may cause damage to servicing instruments.
- Many receivers use a polarized line cord (one wide pin on the plug).
 Defeating this safety device may create a potential hazard to the servicer and the user. Extension cords which do not incorporate the polarizing feature should never be used.
- 9. After re-assembly of the set, always perform an ac leakage test or resistance test from the line cord to all exposed metal parts of the cabinet. Also, check all metal control shafts (with knobs removed), antenna terminals, handles, screws, etc. to be sure the set is safe to operate without danger of electrical shock.

* Broken line: -----

Implosion

- All picture tubes used in current model receivers are equipped with an integral implosion system.
 - Care should always be used, and safety glasses worn, whenever handling any picture tube. Avoid scratching or otherwise damaging the picture tube during installation.
- 2. Use only replacement tubes as specified by the manufacturer.


X-radiation

- Be sure procedures and instructions to all your service personnel cover the subject of X-radiation. Potential sources of X-rays in TV receivers are the picture tube and the high voltage circuits. The basic precaution which must be exercised is to keep the HV at the factory recommended level.
- To avoid possible exposure to X-radiation and electrical shock, only the manufacturer's specified anode connectors must be used.
- It is essential that the service technician has available at all times an accurate HV meter. The calibration of this meter should be checked periodically against a reference standard.
- 4. When the HV circuitry is operating properly there is no possibility of an X-radiation problem. High voltage should always be kept at the manufacturer's rated value no higher for optimum performance. Every time a color set is serviced, the brightness should be run up and down while monitoring the HV with a meter to be certain that the HV does not exceed the specified value and that it is regulated correctly.
 - We suggest that you and your service technicians review test procedures so that HV and HV regulation are always checked as a standard servicing procedure, and the reason for this prudent routine be clearly understood by everyone. It is important to use an accurate and reliable HV meter. It is recommended that the HV reading be recorded on each customers' invoice, which will demonstrate a proper concern for the customers' safety
- When troubleshooting and making test measurements in a receiver with a problem of excessive high voltage, reduce the line voltage by

- means of a Variac to bring the HV into acceptable limits while troubleshooting. Do not operate the chassis longer than necessary to locate the cause of the excessive HV.
- 6. New type picture tubes are specifically designed to withstand higher operating voltages without creating undesirable X-radiation. It is strongly recommended that any shop test fixture which is to be used with the new higher voltage chassis be equipped with one of the new type tubes designed for this service. Addition of a permanently connected HV meter to the shop test fixture is advisable. The CRT types used in these new sets should never be replaced with any other types, as this may result in excessive X-radiation.
- It is essential to use the specified picture tube to avoid a possible X-radiation problem.
- 8. Most TV receivers contain some type of emergency "Hold Down" circuit to prevent HV from rising to excessive levels in the presence of a failure mode. These various circuits should be understood by all technicians servicing them, especially since many hold down circuits are inoperative as long as the receiver performs normally.

Leakage Current Cold Check

- Unplug the ac line cord and connect a jumper between the two prongs of the plug.
- Turn on the power switch.
- 3. Measure the resistance value between the jumpered ac plug and all exposed cabinet parts of the receiver, such as screw heads, antennas and control shafts. When the exposed metallic part has a return path to the chassis, the reading should be between 1 megohm and 5.2 megohms. When the exposed metal does not have a return path to the chassis, the reading must be infinity. Remove the jumper from the ac line cord.



Leakage Current Hot Check

- Do not use an isolation transformer for this test. Plug the completely re-assembled receiver directly into the ac outlet.
- Connect a 1.5k ohm, 10 watt resistor paralleled by a 0.15uF. capacitor between each exposed metallic cabinet part and a good earth ground such as a water pipe, as shown above.
- Use an ac voltmeter with at least 5000 ohms/volt sensitivity to measure the potential across the resistor.
- 4. The potential at any point should not exceed 0.75 volts. A leakage current tester may be used to make this test; leakage current must not exceed 0.5 milliamps. If a measurement is outside the limits specified, there is a possibility of shock hazard. The receiver should be repaired and re-checked before returning it to the customer.
- Repeat the above procedure with the ac plug reversed. (Note: An ac adapter is necessary when a polarized plug is used. Do not defeat the polarizing feature of the plug.)

Picture Tube Replacement


The primary source of X-radiation in this television receiver is the picture tube. The picture tube utilized in this chassis is specially constructed to limit X-radiation emissions. For continued X-radiation protection, the replacement tube must be the same type as the original, including suffix letter, or an N.A.P. Consumer Electronics Corp. (NAPCEC) approved type.

Parts Replacement

Many electrical and mechanical parts in NAPCEC television sets have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. The use of a substitute part which does not have the same safety characteristics as the NAPCEC recommended replacement part shown in this service manual may create shock, fire or other hazards.

COMMODORE STOCKED PARTS — 1084P

CBM PART NUMBER	DESCRIPTION	LOCATION	PHILIPS OEM NUMBER
314890-01	SERVICE MANUAL 1084		
314851-01	CABLE 1084 (6 to 23)		
610200-11	LINE CHOKE	S102	3693400001
610200-12	DEGAUSSING COIL	S104	3693100005
610200-13	DEFLECTION YOKE (PART OF CRT)	S348	_
610200-14	TRANSFORMER	T101	3090200003
610200-15	HORZ DRIVE TRANSFORMER	T401	3293000001
610200-16	OUTPUT TRANSFORMER	T402	3291000006
610200-17	CAP .0082 μF, 1.5KV POLY FILM	C467	2602320549
610200-18	CAP .022 μF, 400V POLYPROP	C468	2602320597
610200-19	DUAL PTC	R104	4H11640035
610200-20	FOCUS CONTROL, 59M	R732	2204290730
610200-21	POWER SWITCH	SK1	1606780548
610200-22	IC OPTIC COUPLER	IC101	5303110001
610200-23	IC AUDIO AMP	IC301	6123300289
610200-24	IC VERT SIGNAL PROCESSOR	IC302	6123300289
610200-25	IC HORZ SIGNAL PROCESSOR	IC402	6123300330
610200-26	IC VIDEO PROCESSOR (28 PIN)	IC501	6123300332
610200-27	IC VIDEO AMP	IC502	6192080240
610200-28	TRANSISTOR NPN TS461	TS461	6105350003
610200-29	TRANSISTOR NPN TS467	TS467	6104330001
610200-30	TRANSISTOR NPN TS711, 712, 713	TS711	6104390001
610200-31	DIODE D107, 108, 109, 110	D107	5391200341
610200-32	CRT WITH DEFLECTION YOKE	B100	M34EAQ10X
610200-33	CRT SOCKET	_	1892250011
610200-34	CABINET (CM8562)	_	1492100005
610200-35	CONTROL PANEL DOOR	. —	1492180018





Computer Systems Division 1200 Wilson Drive West Chester, PA 19380

1084S.P.STOCK 12/09/88

COMMODORE STOCKED PARTS - 1084S-P

CBM PART NUMBER	DESCRIPTION	LOCATION	PHILIPS OEM NUMBER
314890-01	SERVICE MANUAL 1084S-P		
314851-01	CABLE 1084 (6 TO 23)		
602200-60	LINE CHOKE	S102	4822 157 52228
602200-25	COIL, DEGAUSSING	S104	4822 157 52274
602200-59	TRANSFORMER POWER	T101	4822 142 60379
602201-85	TRANSFORMER HORZ DRIVE	T401	4822 146 21263
602201-86**	TRANSFORMER OUTPUT	T402	4822 140 10349
602201-31	CAP .0082 uF, 1.5KV POLY FILM		4822 121 43061
602201-32	CAP .022 uF, 400V POLYPROP		4822 121 20237
602200-53	RES P.T.C. DUAL	R104	4822 116 40035
602200-95	POTM, 59M FOCUS CONTROL	R732	4822 101 20821
602200-28	SWITCH, POWER	SK1	4822 276 11501
602200-76	IC OPTIC COUPLER CNX62	IC101	
602202-10	IC AUDIO AMP TDA 2611AQ	IC301	4822 209 80444
602202-11	IC VERT SIG TDA2653A	IC302	5322 209 82945
602202-14	IC HORZ SIG TDA2595/V4 16P	IC401	4822 209 72155
602202-22	IC VIDEO TDA 4570 28P	IC501	4822 209 71398
602202-23	IC VIDEO AMP TDA3505	IC502	4822 209 71971
602202-18	TRANSISTOR NPN BC639	TS461	4822 130 41053
602201-00	TRANSISTOR BF869	TS711	4822 130 41773
602200-64	DIODE GP15J	D107	4822 130 33887
602200-22	CRT	B100	4822 131 20149
602200-85	CRT SOCKET		4822 255 70217
602200-03	CABINET (CM8562)		4822 701 10567
602200-06	COVER CONTROL PANEL DOOR		4822 701 10568


^{**} T402 USED IN UNITS MANUFACTURED PRIOR TO JUNE 1988.

T402 FOR UNITS MANUFACTURED AFTER JUNE 1988 USE OEM PART NUMBER 3138 138 30100 (HAVE FOCUS CONTROL AND BRIGHTNESS MOUNTED) ARE AVAIABLE IN 1084S-P REPAIR KIT, CBM PN# 314891-01.

314891-01	KIT.	1084S-P	REPAIR

INCLUDES:


314892-01	OUTPUT TRANSFORMER	T402	3138 138 30100
314893-01	RESISTOR 15K, 2W	R475	2120 105 90C63
314894-01	CAP .047 uF MYLAR	C476	2222 368 45473
314895-01	WIRE PVC ORG, 24 AWG	-	0722 183 00004
314896-01	CAP .0056 uF, 50V CERAMIC	C356	2020 552 90817
314897-01	CAP .022uF, 50V CERAMIC	C561	2020 550 90526
314898-01	TNSTRUCTTONS		



FOR REFERENCE ONLY


OEM — Philips Schematics

Sheet 1 of 3



FOR REFERENCE ONLY

1084 Monitor
OEM — Philips Schematics
Sheet 2 of 3



1084 Monitor
OEM — Philips Schematics
Sheet 3 of 3



from the archives of

http://retro-commodore.eu